

EPICS-LabVIEW Integration Discussion

Joseph Z. Xu


APS CTLS

Argonne National Laboratory










EPICS-LabVIEW (LV) Needs




- LabVIEW IOC/UI: End user LabVIEW IOC that needs to interface with EPICS IOCs.
- LabVIEW IOC: Ad-Hock (PXI) IOC running LabVIEW, "touches and feels" like an EPICS IOC.
- LabVIEW based Control System (CS) with EPICS scalability.

Argonne National Laboratory










ActiveX EPICS-LabVIEW Interface

Developed by Kay-Uwe Kasemir at the LANL, this interface

Conforms the EPICS CA library to ActiveX interface.

Uses LabVIEW's ActiveX interface to access the EPICS CA

library



FSM: LabVIEW FSM

GUI: LabVIEW GUI

PCAS: Portable CAS

CAC: Channel Access Client

: LabVIEW Dev Module


: ActiveX Module

Argonne National Laboratory









It provides...

 Easy access to LabVIEW data via PVs over CA without a whole lot of EPICS.

In LabVIEW, using PVInit.vi, PVConfig.vi, PVSet.vi, PVCheck.vi, ..., and PVClose.vi to initialize, configure, set, check, and close a PV.

- PVs can be created and destroyed dynamically.
- Each PV has the following configurable attributes:


PV Name; Value; Data type (unit); Precision; Control, Warning, Alarm, and Graphic HIHI/LOLO.

Argonne National Laboratory









Users all across the globe


- · ALS, LBNL
- · APS, ANL
- CEA-CNRS CEA-Saclay (France)
- Duke Univ.
- GSI (Germany)
- · Italian National Nuclear Physics Institute (Italy)
- · LEDA, LANL
- New Mexico State Univ.
- · NSLS, BNL
- · SLAC
- Synchrotron Laboratory at Barcelona (Spain)

Argonne National Laboratory









What people like

- · Simple to use interface.
- Easy access to EPICS PVs from LabVIEW systems.
- Don't have to know a whole lot of EPICS to use the interface.
- Don't have to know C/C++ to program.

Argonne National Laboratory









Issues

Limited PV Num:

Limited to 32.

PV Attributes:

Doesn't support full attributes.

Event/Interrupt:

- Only support "Polling" mechanism.
- Doesn't support PV asynch call-backs.

Performance:

- Asynch get/put: 0.04ms/0.17ms
- Synch get: 63ms.

Argonne National Laboratory









Additional features wanted


- Support full PV attributes
- · Alarm states.
- Event timestamps consistent with other IOCs.
- Time synchronization with EPICS time server.
- PV bundling.

Argonne National Laboratory










EPICS Shared Memory CAS/CAC

Developed by Dave Thompson and Willem Blokland at the SNS, this approach

 Adds an access interface to the standard EPICS records via device support using Shared Memory. (SM.dll library calls).

Links LabVIEW variables to EPICS PVs via the Shared

Memory.



FSM: LabVIEW FSM

DBE: Data Base Engine

GUI: LabVIEW GUI

DB: Data Base Records

: LabVIEW Dev Module

: Share Memory Interface


DB: Data Base Records

Argonne National Laboratory









It has the full feature of EPICS


- Almost all the capabilities of an iocCore.
 Start the EPICS IOC by running epicsSM.exe with st.cmd as an argument.
- iocCore functionality using Shared Memory and LabVIEW as "device support"
 - In LabVIEW, using SM_Get.vi, SM_Set.vi, SM_Interrupt.vi, ..., and SM_Utility.vi to get, set, and configure the values of an EPICS PV.
- PVs are "pre-defined" as in the EPICS IOC. They are read from and written to the shared memory from within LabVIEW.
- PVs can be grouped together into interrupt groups to make the operation much more efficient.

Argonne National Laboratory









What people like


- Supports EPICS like db.
- Faster execution.
- Newer version supports db configuration and IOC initialization.

Argonne National Laboratory









Shared Memory Issues

Flexibility:

 With Win32 iocCore, all PVs have to be pre-defined. Not as flexible as that of the ActiveX.

Scalability:

 Logic programs (FSM) access DBs via shared memory APIs directly instead of via CAC mechanism.

LV to Epics:


- LV doesn't support Callback function.
- LV has different data type format.

Argonne National Laboratory









Additional features wanted


- Timestamps
 - Provide event receiver to implement precise timestamps and event driven actions.
 - Comply with EPICS Time Server to sync with other servers.
- I/O event record processing.
- Asynch I/O completion callbacks.
- Others

Argonne National Laboratory









EPICS-LabVIEW Future

- Both ActiveX and Shared Memory approaches have sufficient advantages to pursue a tighter integration with LabVIEW.
- The functionality of each approach can be enhanced.
- What we want to see "out-of-the-box" from NI?
- Specifications to NI.
- · Other issues.

Argonne National Laboratory









Possible EPICS-LabVIEW Interface

Flexibility:

 CAS/CAC become part of LabVIEW (RT), LabVIEW can "talk" EPICS on Windows, Linux, Unix, RT, and PDA OS's.

Scalability:

- Support modular architecture.
- Will be able to port the existing EPICS like .db format as needed.

LV to Epics:

- Support Callback function.
- Support "C" type data formats.

"A busy and powerful Community..." - Dr. Holger

Argonne National Laboratory





