

Proton Radiography: Applications in Imaging

Matthew Freeman, for the pRad collaboration

LA-UR-15-28693

UNCLASSIFIED




The Challenge: Image Dense, Rapidly Evolving Systems



Slide 2




[1] W. C. Röntgen, Nature 53 (1896) 274.




Flash radiography of hydrotest implosion (Manhattan project)



Static






Dynamic

- •15 MeV betatron X-ray source
- •1 µsec long pulses
- •Wilson cloud chamber detector






Operated by Los Alamos National Security, LLC for the U.S. Department of Energy's NNSA


Slide 4

High dynamic range and temporal sensitivity visualize delicate, evolving systems



(P.I.: William Buttler)






UNCLASSIFIED




Spall material failure

(P.I.: David Holtkamp)








pRad can investigate fundamental properties of various metals in extreme conditions

UNCLASSIFIED



User programs reach out to new applications

- user programs provide experimenters the opportunity to work at pRad
- classified or unclassified
- yearly call for proposals
- beam time allocated based on Program Advisory Committee recommendations





EST 1943

Operated by Los Alamos National Security, LLC for the U.S. Department of Energy's NNSA


UNCLASSIFIED

Slide 7

Protons are gaining acceptance for cancer therapy in the U.S.







- cancer treatment techniques are evolving and improving
- currently 16 proton therapy centers in the U.S., 10 more under construction
- typical proton energy ~ 200 MeV

UNCLASSIFIED



Protons increase dose-delivery accuracy







image courtesy Nancy Mendenhall, UF Proton Therapy Institute




conventional

plans courtesy Francis H. Burr Proton Therapy Center, MGH, Boston: 45y/o male with benign cerebral meningioma in the petro-clival junction




New technology cuts cost and increases beam energy





Graphic from Nature Clinical Practice Oncology http://www.nature.com/nrclinonc/journal/v1/n2/fig_tab/ncponc0090_F1.html

- higher energy → increased precision
- to take advantage of increased precision you need *in situ* imaging



Lateral scattering of proton beams at two different energies after 15 cm in water.

Simulation by SRIM2011.



Slide 10

Enhanced contrast delineates soft tissue w/ inverse collimator



proton radiograph of an adult zebrafish





Astronauts Sergei Krikalev and John Philips on board the International Space Station with MATROSHKA, built by the German Space Agency (DLR) for dosimetry.




proton radiograph of the head of the anthropomorphic phantom MATROSHKA.



Anthropomorphic Matroshka phantom shows great promise for medical applications of this technique.





- complete 3D information rivaling the gold-standard medical CT
- 200 µm slices (every 16th shown)


UNCLASSIFIED



Proton radiography provides high resolution 3D information



1 cm




- Fine details visible, showing excellent resolution
- New collimators informed by modeling continue to enhance contrast in soft tissue, even more so with targeted gold nano-particles.






A magnetic lens focuses the proton beam similar to glass lenses focusing light








Operated by Los Alamos National Security, LLC for the U.S. Department of Energy's NNSA

Slid<u>e 15</u>



Operated by Los Alamos National Security, LLC for the U.S. Department of Energy's NNSA

Slid<u>e 16</u>

New collimator exploits known scatter to enhance contrast



detector placed at Fourier (scattering angle) plane

scatter introduced by object:

$$\theta_o = \frac{13.6 MeV}{\beta p} \sqrt{\frac{x}{X_o}} \left[1 + 0.038 \ln \left(\frac{x}{X_o} \right) \right]$$

Fourier-plane images

i canor plane imagee	
COPPER - 1 mm	TUNGSTEN - 1 mm
•	
COPPER - 1 cm	TUNGSTEN - 1 cm
	cm

<u>10 cm</u>




Operated by Los Alamos National Security, LLC for the U.S. Department of Energy's NNSA

New collimator exploits known scatter to enhance contrast




Slide 18




Modeling the proposed collimator informs design changes


PROTON PAT








Monte-Carlo simulation








Modeling the scatter-acceptance angle for biological relevance




Slide 20





Conclusions



- 800 MeV proton radiography continues to find new applications, providing new information to measure properties of dynamic materials
- Proton radiography research for national security and medical imaging development are mutually beneficial
- Preliminary studies by an external user collaboration may enable vastly improved precision in proton cancer treatment







UNCLASSIFIED



Acknowledgements



Los Alamos National Laboratory, Los Alamos, NM 87545, USA:

F. Merrill, D. Tupa, M. Freeman, A. Tainter, R. Simpson, A. Saunders, C. Morris, B. Hollander, C. Danly, F. Mariam, M. Murray, C. Espinoza, J. Medina, D. Morley, J. Lopez, M. Martinez, P. Medina, T. Schurman, F. Trouw, T. Sisneros, J. Goett III, J. Allison, J. Tybo, K. Kwiatkowski, W. Vogan McNeil, P. Nedrow, C. Wilde, M. Espy

GSI Helmholtzzentrum für Schwerionenforschung GmbH, Planckstraße 1, 64291 Darmstadt, Germany

M. Prall, C. Graeff, C. LaTessa, P. Simoniello, D. Varentsov

Deutsches Zentrum für Luft- und Raumfahrt (DLR), Lindner Höhe 51147 Cologne, Germany

T. Berger, B. Przybyla

Technische Universität Darmstadt, Schlossgartenstraße 9, 64289 Darmstadt, Germany

M. Durante, P. M. Lang

Frankfurt Institute for Advanced Studies (FIAS), Ruth-Moufang-Straße 1, 60438 Frankfurt am Main

L. Shestov





UNCLASSIFIED

